



Step 3: Download the update software on a computer.

<https://anceltech.com/support/download>




Step 4: Click the software and install the update tool.

(1)





(2)




Step 5: Find this software on your computer and open it.





Step 6: Select connection mode “USB” and click “OK” to continue. The “Product Serial Number” will be read automatically, then hit “Device Upgrade”.




Step 7: Move to the register page, type your email address and Register Code will be read automatically, then hit “Submit”.



Step 8: Choose “Select All” and click “Download” to start downloading.



Step 9: When the 2 progress bars reach 100%, the upgrade completes. Click “Quit” and disconnect the USB cable.



How to check if the FX2000 has installed the latest software?

Connect the FX2000 to a computer and open the update tool. If the local version is the same as the latest version, it has installed the latest version of the software.

