

1. Perfil do produto

Este dispositivo é um novo dispositivo de diagnóstico de problemas de veículos baseado em Android desenvolvido para aplicativos de Internet. Caracteriza-se por cobrir uma ampla gama de veículos, apresentando funções poderosas e fornecendo resultados precisos. Através do conector OBD de diagnóstico do veículo e dos terminais inteligentes móveis variantes, ele obtém o diagnóstico de problemas do veículo para o modelo de carro completo e veículo de sistema completo.

Enquanto isso, aproveitando a Internet móvel, este dispositivo integra mais aplicativos e serviços, como banco de dados de manutenção, assistente remoto, One Key Upgrade etc.

2. Características

- **função de diagnóstico**

Diagnosticar o sistema de controle eletrônico dos modelos de veículos predominantes na Ásia, Américas e Europa. As funções de diagnóstico incluem: Ler DTC, Limpar DTC, Ler fluxo de dados, Funções especiais, etc.

Funções de classificação: Incluindo Moto Diag, Serviço etc.

Projetado especificamente para a plataforma Android, a interface é simples e bonita e a operação é simples.

- **centro pessoal**

Informações do usuário e informações de configuração do dispositivo.

- **Gestão de dados**

Incluindo gerenciamento de arquivos, reprodução de dados, modelo de desinstalação, oficina, visualizador de imagens.

- **Apoiar**

Equipado com banco de dados poderoso. Grande número de vídeos ajudam os usuários a operar o dispositivo facilmente.

- **Definições**

Definir VCI Info, Language, Unit, Network Test, Clear cache, Settings, DC Calibrate and About etc.

- **Melhoria**

O modo WIFI integrado pode realizar o download de aplicativos e a função de diagnóstico por atualização de uma tecla.

3. Conhecimento deste dispositivo

- **todo o conjunto**

Este dispositivo é composto por um computador tablet, um cabo de teste principal e alguns tipos de cabos.

- **o computador tablet**




4. Parâmetros técnicos

- Sistema operacional: Android 5.1.1
- CPU: RK3128 Quad-Core, ARM Cortex A7@1.2Ghz
- Battery: 3700mAh, rechargeable polymer lithium battery
- Extension memory card: 32G Micro SD (TF) card supported
- LCD: 7.0 inch
- LCD resolution: 1024*600
- Touch screen: Capacitive touch screen
- Wi-Fi: supported
- Working temperature: -10°C ~ 55°C (14°F ~ 131°F)
- Storage temperature: -20°C ~ 70°C (-4°F ~ 158°F)
- Weight: about 0.76 Kg
- Dimension: 245mm*150mm*36mm

5. Accessories (Standard Configuration)

- **Main test cable**

Pack different main cable according to different configurations




- **Other Connectors**

Other connectors are used to connect the diagnosis socket of non OBD II vehicles. To choose the connector according to the vehicle brand and models.




Note: Different configurations may choose different accessories.

- **Others accessories**

DC Power Adapter (Output DC 12V/2A), To power up the tablet via connecting with outside power Supply.



6. Charge This Device

1. Connect the included USB cable with charger.
2. Plug the charger into AC outlet.
3. When it connects to charger, battery logo indicates , it indicates that the battery is in charging.
4. When battery logo changes into , it indicates that the battery is fully charged.
5. Unplug USB cable on the charger from this device. 

7. Using Battery

- If the battery keeps unused for a long time or battery is completely discharged, it is normal if it cannot be turned on while being charged. Please charge it for a period and then turn it on.
- Using data service will cause more power consumption and shorten the stand by time.
- The charging time of battery varies with temperature condition and battery consumption status.
- While this device has low battery, a beep will sound. If it is very low, this device will be switched off automatically.





Note: Do one of the followings to save power:

- When this device keeps unattended, press POWER key to turn off the LCD.
- Shorten the standby time: Enter the main menu, choose "Settings" > "DEVICE" > "Display" > "Sleep" to select a shorter standby time.
- Decrease the brightness of LCD display: Enter main menu, choose "Settings" > "DEVICE" > "Display" > "Brightness", and then drag the slider to adjust it.
- Change "Live wallpaper" into "Gallery".
- Set Bluetooth off: Enter the main menu, choose "Settings" > "Bluetooth", and then toggle the switch to OFF.
- Press VOLUME key to decrease the volume.

8. Power On/power off This Device

- Power on
Press and hold Power button for three seconds to turn on this device.
- Power off
Press and hold Power button for three seconds to turn off this device.

9. About Desktop

ICON	FUNCTION	DESCRIPTION
	Back button	Go back to previous interface or exit program.
	Print screen	Make a quick screenshot and save it to gallery.
	Home button	Return to the desktop.
	Touch screen menu button	Press this key to quickly switch between open windows.



DP button

Enter diagnose and program interface.



VCI button

Enter system settings.

10. Customize Your Desktop

- **Add items on the desktop**

On the main menu, hold and press the desired item, the system will automatically enter the desktop and place the icon into the circle. Hint: If many applications occupy the desktop, hold and press the desired one to move it to other extension desktop.

- **Move items on the desktop**

Hold and press the item to be moved. After a movable circle appears on the screen, drag it to the target location.

- **Delete items on the desktop**

Hold and press the desired item, "Delete" appears in the upper middle of the screen. Drag the item to "Delete". When the item and icon turn red and then release it.

- **Change your wallpaper**

Hold and press a blank area on the desktop, a pop-up wallpaper will be shown on the screen. Choose desired wallpaper. Click upper left corner "√" to set wallpaper.

- **Create a folder on the desktop**

Drag one icon to another icon, the system will create a folder. Input the folder name.

11. On Using Touch Screen

- Tap: Tap the corresponding item with your finger to confirm the selection or start the application.
- Long press: Long press the icon or input field to open the operation option menu of the current interface.
- Slide: Slide your finger horizontally or vertically on the screen.
- Drag: Long press the selected item with your finger, and then drag the item to any position on the screen.

12. Lock & Unlock

- **Lock the screen**

- When the device is ON, press POWER key to lock the screen.
- The system will lock the screen automatically if after this device remains idle for a long time.

- **Unlock the screen**

- Press POWER key to activate the screen and then drag the lock to "Unlock position."

13. Notification Bar

The notice bar is used to display some activities, messages to remind and inform users.

- **Turn on the notification panel**

- When a new notification icon appears on the status bar, slide the status bar downwards to open it.
- In the notification panel, click the desired notification item to open it.

- **Turn off the notification panel**

- When the notification panel is opened, click on the blank space of the screen and the notification panel will automatically retract.

14. Input Method

- **Set input method**

- Enter main menu and then select "Settings" -> "Personal" -> "Language&input" to Choose desired input method.
- The default input method supports a powerful thesaurus engine, multiple keyboard modes. Android keyboard and Google input method and make input easier. To start text input modes, please click any text input entry.


15. How to Set as Airplane Mode

- According to the regulations of some countries or regions, PC device must be turned off before boarding on the airplane.
- The way to disable functions of this device is to set it as airplane mode. In this mode, all wireless radio waves will be off, including mobile network, Bluetooth and WLAN.
- Do one of the followings to enable or disable airplane mode:
- Press POWER key and choose "Airplane mode" from the pop-up option menu.
- Access the main menu, and choose "Settings" > "WLAN" > "More" > "Airplane mode".

Observações: Certifique-se de que a conexão com a Internet esteja normal durante a atualização. Além disso, devido a muitos softwares, pode levar vários minutos, aguarde pacientemente.

1. Atualização do sistema de detecção

O APK do sistema detecta automaticamente a versão. Se houver uma atualização de versão, um ponto vermelho estará no canto superior direito do botão de atualização. Clique no botão de atualização para perguntar "Quer atualizar o software?".



Se você escolher "ESC" para não atualizar, ele retornará diretamente para a interface principal; se você escolher "Enter", a atualização do APK e um prompt de instalação serão exibidos.

DP DiagProgram

Do you want to install an update to this built-in application? Your existing data will not be lost. The updated application will get access to:

NEW

ALL

This update requires no new permissions.


CANCEL

INSTALL



09:28

Clique em "INSTALAR" para atualizar e instalar o APK, após a atualização e atualização, um aviso aparecerá e clique em "Concordo" para entrar na interface da função de diagnóstico.





2. Diagnostic Function Upgrade

If more than one downloaded model diagnosis software needs to be updated, download and upgrade software by "Bulk Update". The software provided in the following operations is only for reference and guidance.

Upgrade 				
<input type="checkbox"/>	Software name	Local latest version	Downloadable	[0/17] Bulk Update 
<input type="checkbox"/>	DIAG-MOTORCYCLE- BMW	—	33.15 ▼	4.61 MB
<input type="checkbox"/>	DIAG-MOTORCYCLE- BRP	—	30.08 ▼	4.02 MB
<input type="checkbox"/>	DIAG-MOTORCYCLE-HONDA	—	30.19 ▼	2.91 MB
<input type="checkbox"/>	DIAG-MOTORCYCLE-OBD-II	—	30.22	1.90 MB
<input type="checkbox"/>	DIAG-MOTORCYCLE-KTM	—	30.37 ▼	4.88 MB
<input type="checkbox"/>	DIAG-MOTORCYCLE-POLARIS	—	30.05 ▼	4.89 MB
<input type="checkbox"/>	DIAG-MOTORCYCLE-VICTORY	—	30.07 ▼	4.32 MB

Click the check box in front of the software name, and then click "Bulk Update" to start downloading and updating.

Upgrade 				
<input checked="" type="checkbox"/>	Software name	Local latest version	Downloadable	[0/17] Loading... 
<input checked="" type="checkbox"/>	DIAG-MOTORCYCLE- BMW	—	33.15 ▼	Loading... (0/0)0.00 KB 0.00 KB/s
<input checked="" type="checkbox"/>	DIAG-MOTORCYCLE- BRP	—	30.08 ▼	Loading... (0/4)0.00 KB 0.00 KB/s
<input checked="" type="checkbox"/>	DIAG-MOTORCYCLE-HONDA	—	30.19 ▼	Loading... (0/4)3.51 MB 583.17 KB/s
<input checked="" type="checkbox"/>	DIAG-MOTORCYCLE-OBD-II	—	30.22	Queuing
<input checked="" type="checkbox"/>	DIAG-MOTORCYCLE-KTM	—	30.37 ▼	Queuing
<input checked="" type="checkbox"/>	DIAG-MOTORCYCLE-POLARIS	—	30.05 ▼	Queuing
<input checked="" type="checkbox"/>	DIAG-MOTORCYCLE-VICTORY	—	30.07 ▼	Queuing

If a software needs to be canceled, just tap the corresponding Check Box. You can search for the updated model required in the search box (Fuzzy Search function). As the following photo shown:



After the upgrade is completed, you can enter the diagnostic programming to view the upgrade version description and the version number, and you can perform related diagnostic operations and functions.

1. Conecte o Conector VCI

- **Procedimento para conectar o conector VCI:**

1. Localize o soquete de diagnóstico das motocicletas. Os conectores do soquete de diagnóstico de diferentes modelos são inconsistentes. Você precisa usar o adaptador de modelo correspondente. Você pode verificar a localização aproximada do adaptador de modelo no bitmap de diagnóstico nos dados do software.
2. Conecte o conector de diagnóstico deste dispositivo no soquete de diagnóstico.


2. Fluxograma de diagnóstico

Para novos usuários, siga o passo 3 para operar e começar a usar o produto.

Conecte o conector de diagnóstico -> registro do usuário -> login do usuário -> download ou atualização do software -> selecione a função ou o tipo de veículo -> prossiga com o diagnóstico

3. Centro Pessoal

Usado para configurar e gerenciar detalhes da conta, e você pode visualizar as informações do revendedor:



- **Cadastro de usuário**

Entre na interface do Personal Center, exiba a interface de login, clique no botão "Registrar" no canto inferior direito para entrar na interface de registro do usuário. Como mostrado:

Account information

Contact information

Register success



Username



Password



Confirm password



Email(password retrieve by Email)

Next

Back to login

Forgot password



09:18

Account information

Contact information

Register success

For better service, fill in the info carefully!



Contacts



Cellphone



Company name



Address




Post Code

Register


Previous



09:18




Preencha as informações em cada campo. Depois disso, o registro foi bem-sucedido, clique em "Login now!" Se você se registrou como membro, clique em "Login do usuário" para entrar na página de login do usuário. Como mostra a imagem a seguir:




- **Login de usuário**

Após a conclusão do cadastro, preencha o número da conta e senha e clique em login:




Exibir informações pessoais básicas e modificar informações e senha.

- **Modificar informações**




- **Mudar senha**




- **Exibir informações do distribuidor**

Clique em "Mostrar informações" para visualizar as informações de contato do distribuidor.




- **Recuperar Senha**

Clique na senha esquecida na interface de login para entrar na interface de recuperação de senha, preencha as informações relevantes para recuperar a senha.




- **Recarregar CRÉDITO**

Clique em "Recarregar CRÉDITO" para recarregar através de 2 métodos de contato.




- **Central de Autorização**

Clique em "Centro de Autorização" para a assinatura anual e atualização de configuração. (Nota: esta função não está ativa no momento)




- **Histórico de pedidos**

Clique em "Histórico de pedidos" para visualizar o histórico de pedidos.



4. Introdução à interface principal do software de diagnóstico



A interface principal é dividida nas seguintes funções:


FUNÇÃO	DESCRIÇÃO
Moto Diag	Entre na função de programação de diagnóstico da motocicleta.
Service	Enter the service function.
Personal Center	New user registration, login; User details management, dealer information inquiry.
Data Management	Including File Management, Data Playback, Uninstall Model, Workshop, Picture Viewer.
Support	Including Video, Manual, FAQ, Log Upload and TeamViewer.
Settings	It includes VCI Info, Language, Unit, Network Test, Clear cache, Settings, DC Calibrate, About.
Upgrade	To download diagnostic software or upgrade diagnostic software to the latest version.

5. Start Diagnosing

Click "Moto Diag" in the main interface to enter the function selection and model selection interface, and enter the "All" menu path by default. Different product configurations are equipped with different software, please refer to the actual software. The software provided in the following operations is only for reference and guidance.



Select the Favorites menu, click "+" to enter the interface of selecting vehicle series of each area, check the box in the upper right corner of the vehicle logo, and then click "Add" in the upper right corner of the interface to add to Favorites.






Delete the favorite vehicle series from Favorites, click "-" to enter the interface of the favorite vehicle series. Check the box in the upper right corner of the vehicle logo, and then click "Delete" in the upper right corner of the interface to delete from Favorites.



You can see all the downloaded software of the machine configuration. OBD II software defaults to each area, and in the first position:




The following takes OBD II as an example to introduce how to start the diagnosis. Click the “OBD-II Engine” icon under the menu of other special functions and select the software version, as shown below:



To enter diagnostic function menu, As shown in the figure below:



Select AUTO SCAN, as shown below:



1. Read vehicle information

Tap "Vehicle information". As shown below:

OBD-II		AUTO SCAN		12.51V	
Name	Value				
ECU Mode	\$10				
Calibration Identifications	33D907559H 0050				
					Esc


2. Read Stored Codes

Tap "Stored Codes". As shown in the figure below:

OBD-II		AUTO SCAN		12.5V	
Stored Codes					✓
Pending Codes					
					Esc
					Enter

OBD-II		AUTO SCAN		12.48V
DTC ID	DTC Description	State	Other	
P0122	Throttle/Pedal Position Sensor/Switch A Circuit Low			
P0222	Throttle/Pedal Position Sensor/Switch B Circuit Low			
P0113	Intake Air Temperature Sensor 1 Circuit High			
P0686	ECM/PCM Power Relay Control Circuit Low			
P0118	Engine Coolant Temperature Sensor 1 Circuit High			
				Esc

3. Clear trouble codes



4. Read data stream

OBD-II AUTO SCAN 12.46V

- Number of DTCs 1
- Malfunction Indicator Lamp (MIL) Status 2
- Fuel System 1 Status 3
- Fuel System 2 Status 4
- Calculated Load Value 5
- Engine Coolant Temperature 6
- Short Term Fuel Trim - Bank 1 7

Clear Esc Enter

← 📷 🏠 📁 DP VCI 🔗 📶 📧 09:57

OBD-II AUTO SCAN 12.46V


NO.	Data stream name	Value	Range	Unit
01	Number of DTCs	0		
02	Malfunction Indicator Lamp (MIL) Status	MIL OFF		
03	Fuel System 1 Status	OL		
04	Fuel System 2 Status	Not Used		
05	Calculated Load Value	100.0		%
06	Engine Coolant Temperature	-40		degree C

Esc

← 📷 🏠 📁 DP VCI 🔗 📶 📧 09:58


6. Data Management

You can enter File Management, Data Playback, Uninstall Modle, Workshop and Picture Viewer.




- **File Management**

You can view the related information in the files;



- **Data Playback**

Data stream has the function of recording and playback, which can realize dynamic data comparison with the interface, and can easily and quickly find the abnormal data.



- **Uninstall Model**

You can uninstall related vehicle models;



- **Workshop**

You can use it to set the information of shops;


Workshop

Set store picture		Station Name	<input type="text" value="Enter the store name"/>	
Address	<input type="text" value="Province"/>	<input type="text" value="City"/>	<input type="text" value="Area"/>	<input type="text" value="Enter the detailed address"/>
Store type	<input type="text" value="Private Ent..."/> ▾			
Phone	<input type="text" value="Enter phone number"/>			
Manager Name	<input type="text" value="Enter the name"/>	Manager Title	<input type="text" value="Enter a position"/>	
Email	<input type="text" value="Enter the email"/>	Website	<input type="text" value="Enter the URL"/>	

Edit

- **Picture Viewer**

You can browse the related pictures saved in this machine.




7. Support

We have a powerful maintenance database and detailed product introduction information.



- **Video**
Connect the diagnosis function operation videos of the actual vehicles.
- **Manual**
Introduce the instruction manual of this product, and exhibit the basic information of the equipment, diagnosis instructions, upgrades, other applications and additional explanations of the company's products in the device.



- **FAQ**
Summarize some common problems encountered in the use of the product.


1. Startup failure

In case startup failure occurs, please connect the included DC power supply, and the device will be able to power on when charged. If the battery is too low, it may take a few minutes. If the device is still unable to power on, please contact customer service department and return it to repair. If the temperature is lower than -20°C, it is unable to power on. Please power on in a proper environment, and the device will be not affected by the temperature after startup and can work smoothly.

2. Touchscreen interference

- **Log Upload**


Manually upload the log files generated by the abnormality when diagnosing the vehicle.



- **TeamViewer**

This application can realize remote hosting operation via the Third Party's software: "Quick Support" or "AnyDesk". (If only the Quick Support is detected, you need to use AnyDesk and then you can return to the main menu interface to enter.)

- **Quick Support:**




Your ID 330 144 230

SEND MY ID...

● Ready to connect (secure connection)



○ AnyDesk:



8. Settings

It includes VCI Info, Language, Unit, Network Test, Clear cache, Settings, DC Calibrate and About etc.


- VCI Info



- Language





- Unit




- **Network Test**

The network test function is convenient for network connection failure and other phenomena during use. After submitting test logs, engineers can analyze the network status of the machine through the test logs.







- Clear Cache



- Settings



- **DC Calibrate**



- **About**

Display software version updates and product announcements.

Version v1.1.3

Network Test •

Disclaimer

Clear cache •

Settings •

DC Calibrate •

About •

1. Do not use the product before reading this Terms.
2. Do not operate this product during driving to reduce traffic danger due to lack of concentration. OBDSpace shall not be liable for any traffic accident or economic loss arising from the use of this product.
3. Via Bluetooth or USB products to achieve data acquisition and transmission. To ensure smooth transfer, do not use this product in places with strong electromagnetic interference (e.g. high voltage transmission and distribution equipment).
4. OBDSpace shall not be liable for any direct or indirect damage to the product due to unauthorized modification or adding any component.
5. This software is developed by OBDSpace Technology Co., Ltd. Software



1. Wi-Fi

Esta função permite que você navegue na Internet e baixe dados da Internet via Wi-Fi.

- **Ligue o Wi-Fi**

- Entre na tela do menu principal, escolha "Configurações" > "Wi-Fi".
- Quando o sinal da WLAN aparecer em azul, isso indica que o Wi-Fi já foi ativado.

Observação: para prolongar a vida útil da bateria, desligue o Wi-Fi quando estiver sozinho.

- **Conectar à WLAN**

Ligue o WLAN, se o dispositivo estiver dentro do alcance do WLAN, ele detectará e conectará automaticamente ao WLAN atual, selecione a rede desejada e insira a senha, então você poderá navegar na Internet pelo WLAN.


2. Navegador

Você pode usar qualquer APP por meio de navegar no site e na rede.

- **Abra o navegador**

Entre na interface do menu principal, clique no navegador para abrir a página inicial do navegador, você pode escolher a página inicial desejada ou inserir o endereço do site para navegar.

- Toque para inserir ou editar o link da web.



- Área de exibição da página da Web.
- Toque para abrir os favoritos, ver o histórico e as páginas da web salvas.

- **página do navegador**

- Abra o navegador.
- Insira o endereço da Web e toque em "Ir" no teclado para visitar o site.

Dicas: Como alternativa, você também pode tocar e selecionar "Favoritos/Histórico" na lista suspensa para esc

- Depois que uma página da Web estiver aberta, deslize a tela com a ponta do dedo para visualizar outro conteúdo oculto.

- **Ampliar/diminuir uma página**

Existem duas maneiras de aumentar/diminuir o zoom ao navegar em uma página da web.

- Para aumentar o zoom para que o texto em uma página da web apareça em uma coluna que caiba na tela do seu dispositivo, dê um toque duplo com a ponta do dedo.
- Para aumentar o zoom manualmente, coloque dois dedos na tela e afaste-os. Para diminuir o zoom, toque duas vezes novamente ou afaste dois dedos na tela e junte-os.

- **Salve a página da Web favorita nos favoritos**

- Ao navegar em uma página da web, toque e escolha "Salvar nos favoritos".
- Edite um rótulo para os favoritos.
- Toque em "OK" para confirmar e salve.

- **Abra várias páginas**

O navegador permite abrir várias páginas da Web e você pode alternar entre essas páginas.

- Ao navegar em uma página da web, toque e abra uma nova janela.
- Outra página da Web será exibida na nova janela.

- **Personalizar configurações de internet**

Ao navegar em uma página da web, escolha "Configurações", você pode visualizar ou alterar as configurações do navegador, configurações de privacidade e segurança e configurações avançadas, etc.

3. Galeria

This option is used to manage pictures and video files.

- **Open gallery**

Enter main menu screen, tap "Gallery" to access it. The system searches images and videos in this device and SD card automatically, and categorizes it into corresponding folders.

- **View a photo**

1. Enter main menu screen, tap "Gallery".
2. Tap the picture folder you want to view.
3. Tap the desired image to browse.
4. Swipe the screen rightwards or leftwards to view the next/previous picture.

4. Music


Music files are stored into 4 categories: Artists, Albums, Songs and Playlist. Tap the desired music to display music.

Tips: While playing, tap back button to switch to other applications and the player will be running in background. Open the status bar and choose the audio file to return to the player screen.

5. Calculator



You can use the calculator to perform addition, subtraction, multiplication and division operations, as well as function operations for sin, cos, tan and log.

6. Calendar


This function lets you view calendar or create to-do events. Enter main menu screen, tap "Calendar". Swipe up and down to switch to month; Tap a day, the followings can be done. Tap  to refresh, search, and hide control and setting.

7. Clock

- **Add an alarm**

1. Enter main menu, and tap "Alarm".
2. Tap  to add alarms.
3. Set the detailed information of the alarm.
4. Tap  to pack up the alarm to store the setting.

- **Delete an alarm**






1. Enter main menu, and tap "Alarm".
2. Tap the desired alarm.
3. Tap  to delete it.

Tips: After the alarm is deleted, you can choose to cancel delete alarm on the right side from the option menu.

- **Customize your alarm**






1. Enter main menu, and tap "Alarm".
2. Tap menu button, and then choose "Settings".
3. Alarm volume: Set the volume of alarms.
4. Set the duration of alarm.
5. Set the duration the alarm snooze next time.
6. Volume buttons: set what these buttons function when pressed during an alarm.
7. Set default ringtone: choose the alarm ringtone.

- **Timer setting**

1. Enter the main menu to tap  to choose timer;
2. Set countdown time;
3. Tap  to add timer, and tap  to delete alarm;
4. Tap  to start the timer, and tap  to stop counting down;

Notice: after the countdown ends, the device will ring alarm sound.

- **Stopwatch setting**

1. Enter the main menu to tap  to choose second clock;
2. Tap  to start stopwatch, and tap  to stop second clock;
3. Tap  to reset the stopwatch;
4. Tap  on the right side to display the smaller unit counter of the stopwatch;

8. ES File Explorer

Open ES file viewer, and enter main menu. You can manage SD card, browse by category and browse all music, picture, video, document application, package, favorites, installation package, management recommended through catalogue.

9. Display

- **Brightness**

1. Enter main menu screen, tap "Settings" > "Display".
2. Tap "Brightness" to enter.
3. Drag the slider leftward to lower the screen brightness. Drag the slider rightward to increase the screen brightness.

- **Auto-rotate the screen**

1. Enter main menu screen, tap "Settings" > "Display".
2. When setting the rotation of device, keep the orientation of the rotated screen.

10. Set Screen Lock

You can set a screen lock pattern. When the screen is locked, it will not be unlocked until you draw the right pattern.

1. Enter main menu screen, tap "Settings" > "Security" > "Screen lock".
2. There are several options available for your selection. To define a pattern, follow the on-screen prompts to plot your pattern.
3. After drawing, tap "Confirm" to save your setting.

11. Application

- **View installed applications**

1. Enter main menu screen, tap "Settings" > "Apps" to open the downloaded application list.
2. The following operations can be done:
 - Tap the desired one to view the application information.
 - Tap and choose "Sort by size" from the pull-down menu, the applications will automatically appear in size order.
 - Tap and choose "Reset app preferences" from the pull-down menu, a confirmation dialog box will appear on the screen, tap "Reset apps" to proceed; tap "Cancel" to abort.
3. To uninstall an application, tap it to enter the application information screen.
4. Tap "Uninstall" and then follow the on-screen instructions to finish it.

- **View the running applications**

1. Enter the main menu screen, tap "Settings" > "Apps". Scroll the screen from right to left to RUNNING tab to open the currently running application list.
2. The following operations can be done:
 - View the currently running applications;
 - Tap any one to stop it.

12. Language & Input

- **Language setting:**

1. Enter the main menu screen, tap "Settings" > "Language & input"> "Language".
2. Tap "Language" and choose the desired language in this device.

- **Input method setting:**

1. The device provides several kinds of input methods. Tap setting before the desired input method.

13. Set Date & Time

This device is preset to use the network-provided date, time zone and time. Note: If Automatic date & time is set as Use network-provided time, date, time and time zone will not be defined.

1. Enter the main menu screen, and tap "Settings" > "Date & time".
2. Tap "Set date", and scroll the screen upwards or downwards until the desired numbers appears in the highlight area.
3. Tap "Select time zone", and choose the desired one from the time zone list. Scroll the screen upwards and downwards to view more.
4. Tap "Set time" and scroll the screen upwards or downwards to adjust the hour and minute. After setting, tap "Done" to confirm.
5. Select or deselect "Use 24-hour format" to switch between 12-hour format and 24-hour format.
6. Tap "Choose date format" to choose the desired date of this device format from the list.

14. Restore to Factory Settings

This option enables you to restore this device to the default factory settings. Once it is reset, all data (including downloaded applications) will be deleted. Note: Before resetting to factory data reset, please back up all important data saved in your device.

1. Enter the main menu screen, tap "Settings" > "Backup & reset" > "Factory data reset".
2. Follow the instructions on the screen to proceed.

15. Storage

Enter the main menu, and tap "Settings"> "Storage", check the store situation of the device.Store the download content in the default browser to the download content list.

16. App Installation/Uninstallation

- Install: Put the application package under the root directory of SD card, enter "File Manager" and then tap the desired package to start installing.
- Uninstall: Tap "Settings" > "Apps", and choose the desired one to uninstall.

Declaração oficial: Os nomes de outros produtos mencionados neste manual destinam-se a explicar como este equipamento é usado, e a propriedade da marca registrada ainda pertence à empresa original.

1. Informações de direitos autorais

Sem o consentimento por escrito da OBDSpace Technology Co., Ltd. (doravante denominada "OBDSpace"), nenhuma empresa ou indivíduo deve copiar e fazer backup deste manual de qualquer forma (eletrônica, mecânica, fotocópia, gravação ou outras formas).

Este manual foi elaborado especialmente para a utilização dos produtos OBDSpace, a empresa não assume qualquer responsabilidade pelas consequências causadas pelo uso do mesmo para orientar a operação de outros equipamentos.

Este manual e todos os exemplos nele contidos estão sujeitos a alterações sem aviso prévio.

A OBDSpace e suas filiais não se responsabilizam por quaisquer acidentes causados por usuários ou terceiros, uso indevido do equipamento, modificação e reparo não autorizado do equipamento, ou danos e perdas do equipamento devido ao não cumprimento dos requisitos de operação e manutenção.

A OBDSpace não se responsabiliza por quaisquer danos ou problemas do equipamento causados pelo uso de outros acessórios opcionais ou consumíveis que não os produtos originais da OBDSpace ou os produtos aprovados pela OBDSpace.

Este equipamento é para técnicos profissionais ou pessoal de manutenção.

2. Informações sobre marcas registradas

OBDSpace registrou sua marca registrada na China e em vários países estrangeiros, e seu logotipo é "ANCEL". Em países onde qualquer uma das marcas comerciais, marcas de serviço, nomes de domínio, logotipos e nomes de empresas da OBDSpace não estão registrados, a OBDSpace reivindica outros direitos associados a marcas comerciais, marcas de serviço, nomes de domínio, logotipos e nomes de empresas não registrados. Outros produtos ou nomes de empresas mencionados neste manual podem ser marcas comerciais de seus respectivos proprietários. Você não pode usar qualquer marca comercial, marca de serviço, nome de domínio, logotipo ou nome de empresa da OBDSpace ou de terceiros sem a permissão do proprietário da marca registrada, marca de serviço, nome de domínio, logotipo ou nome da empresa aplicável. Você pode entrar em contato com a OBDSpace visitando o site www.anceltech.com ou escrevendo para OBDSpace Technology Co., Ltd., D03,

3. Precauções de segurança

Antes de usar este dispositivo, leia atentamente as seguintes informações de segurança. Para obter informações mais detalhadas, consulte o apêndice "Avisos e precauções de segurança".

- Nunca colida, jogue ou perfure este dispositivo e evite cair, extrusá-lo e misturá-lo.
- Não use este dispositivo em ambientes excepcionalmente frios ou quentes, empoeirados, úmidos ou secos.
- Em locais onde este dispositivo é proibido ou o uso deste dispositivo pode causar interferência ou gerar um risco potencial, desligue-o.
- Não use este dispositivo enquanto dirige.
- Em locais médicos, observe os regulamentos ou regras relevantes, em áreas próximas a equipamentos médicos, desligue este produto.
- Desligue este dispositivo antes de embarcar em qualquer avião.
- Nunca coloque este dispositivo em aparelhos com forte campo eletromagnético.
- Não desmonte este dispositivo sozinho. Se houver qualquer dúvida, entre em contato com o revendedor.
- Não coloque o produto e acessórios em aparelhos com campos eletromagnéticos fortes.
- Mantenha este dispositivo longe de dispositivos magnéticos porque suas radiações podem apagar os dados armazenados nos dispositivos.
- Não use este dispositivo em alta temperatura e outro ambiente com gás inflamável, como posto de gasolina.
- Mantenha este dispositivo fora do alcance das crianças e não permita que elas o usem sem supervisão.
- Use a bateria e o carregador incluídos. Caso contrário, pode ocorrer explosão.
- Cumpra as leis e regulamentos e respeite a privacidade e os direitos legais das pessoas ao operar este dispositivo.

4. Precauções ao usar este dispositivo

O interruptor de ignição deve estar DESLIGADO ao conectar ou desconectar o conector de diagnóstico.

5. Precauções para operação da ECU

- Do not disconnect the inner consumer when the ignition switch is on. High voltage transients may be encountered when disconnected, which may damage the sensors and the ECU.
- Keep the computer away from magnetic objects.
- Do not cut off the power supply of ECU system before performing any welding operations on the vehicle.
- Pay more attention to the ECU and the sensors when performing any operation near them.
- Ground yourself when you disassemble PROM, otherwise, ECU and sensors will be damaged by static electricity.
- Do not connect ECU harness connector firmly, otherwise, electronic elements, such as IC inside ECU, will be damaged.

6. Safety Warnings and Precautions

Before using or operating the device, please read and observe the following precautions to avoid dangerous or illegal conditions and to ensure the best performance of this device.

7. Medical Equipment

- In the express provision for healthcare facilities that prohibits the use of wireless equipment, please comply with the provisions of the premises to shut down this device.
- Radio waves generated by this device may affect the normal operation of implantable medical devices or personal medical devices such as pacemakers, implantation of cochlea, hearing aids, etc. If you are using these medical devices, consult your manufacturer for restrictions on the use of this device.

8. Flammable and Explosive Area

- Do not use this device at the gas station (repair station) or near flammable materials or chemicals, and follow all graphic or text instructions. This device may cause an explosion or fire in or around the fuel or chemical storage and transport area or in an explosive area.
- Do not store or transport the equipment and its accessories in flame or flammable liquids, gases or explosive materials in the same box.

9. Traffic Safety

- Do not hold this device while driving and comply with the regulations in your area or country.
- Do not place the device above the vehicle's airbag or in the area that can be reached after the airbag is deployed, otherwise when the airbag inflates, the device will be pushed by strong external force, causing serious injury to the occupants.
- The wireless device may interfere with the aircraft's flight system, please comply with the relevant provisions of the airline. When the use of wireless devices is prohibited, please turn off this device.

10. Operating Environment

- Do not charge or use this device in a dusty, humid, dirty, or near magnetic field to avoid malfunction of the internal circuit of the device.
- Do not use this device during thunderstorms to avoid lightning strike or other damage.
- Turn off this device where it is expressly prohibited to use the wireless device.
- When this device is powered by a power adapter, the choice of the product altitude is determined by the matching adapter. For the tropical ambient temperature conditions, keep the ambient temperature between 0°C and 40°C. When this device is powered by batteries, keep the ambient temperature between -10°C and 40°C. Do not use the above temperature range, when the ambient temperature is too high or too low, otherwise, it may cause a malfunction.

11. Child Health

- This device and its accessories may contain small parts, please keep them out of the reach of children.
- Children may unintentionally damage this device and its accessories, or swallow small parts to cause suffocation or other hazards.

12. Environmental Protection

Please comply with local laws and regulations regarding device, batteries and their accessories, and support recycling operations. Do not dispose of device, batteries and their accessories as ordinary household waste.

13. Original Accessories

Use only original accessories provided by the device manufacturer. If you use any non-original accessories, it may affect the performance of this device, violate the warranty terms of this device or the relevant national and regional regulations on communication terminal products, and even lead to personal harm.

14. Use Batteries and Chargers

- When charging is complete, disconnect the device from the power outlet device.
- Do not connect metal conductors to the battery, or touch the end of the battery to avoid short circuits and physical damage caused by burnout due to overheating
- Do not place the battery or device around the heating equipment, such as a microwave oven, oven or radiator.
Batteries may explode when overheated.
- Do not disassemble or modify the battery to prevent the battery from leaking, overheating, igniting or bursting.
- If the battery leaks, do not expose the skin or eyes to the leaked liquid; if it gets on the skin or eyes, rinse immediately with water and go to the hospital for medical treatment.
- If the charger's cable is damaged, do not use it to avoid electric shock or fire.
- Do not throw the battery into the fire, otherwise it will cause the battery to fire and burst.

15. Repair and Maintenance

- Keep this device and its accessories dry. Do not use a microwave oven or other external heating equipment to dry it.
- Do not subject this device and its accessories to strong shock or vibration to avoid damage to the equipment and its accessories or to cause the battery to explode.
- Do not expose the unit or its accessories to excessively high or low temperatures. Doing so may result in malfunction, fire or explosion of the device, battery and charger. When the temperature is below 0°C, the battery performance will be limited.
- Do not use potent chemicals, cleaning agents or strong detergent to clean the device or accessories. Before cleaning and maintenance, please turn off and disconnect the charger.
- Do not disassemble the device and its accessories, otherwise the device and accessories will not be covered by our warranty.
- If the device collides with a hard object or the device is subjected to strong external impact, which causes the screen to break, do not touch or attempt to remove the broken part, stop using it immediately and contact the designated service point in time.

16. Warranty

The warranty is only applicable to users and distributors who purchase the company products through normal procedures. **Within one year from the date of delivery**, OBDSpace warrants its electronic products against defects in materials or workmanship. Damage to the device or components caused by abuse, unauthorized modification, use for purposes not designed for this product, or operation not in accordance with the instructions in the manual is not covered by this warranty.

17. Order Notification

Replaceable parts and optional accessories can be ordered directly from the company authorized supplier, please specify the following when ordering:

- Order quantity
- Serial number
- Part name

18. Customer Service Center

1. If you encounter any problem during the operation, please contact authorized supplier.
2. When the device needs repair, please send it to OBDSpace Technology Co., Ltd. together with the purchase invoice and problem description. If the device is covered under the warranty, company will provide free maintenance; if the device is not under the warranty, company will charge maintenance and return freight.
3. OBDSpace Technology Co., Ltd. After-Sales Service Information:
 - After-Sales Address: D03, Block A, No 973 Minzhi Ave, Longhua District, Shenzhen Guangdong, China
 - After-Sales Email: support@anceltech.com
 - Company Website: www.anceltech.com

19. Declaration

OBDSpace reserves the right to change the product design and specifications without notice. Physical appearance and color may be a little different from the one shown in the instruction, please refer to the device. We have made every effort to make all descriptions in the manual accurate, but some inaccuracies are still inevitable. If in doubt, please contact the dealer or after-sales service center. The company does not bear any consequences due to misunderstanding.

1. Falha na inicialização

Em caso de falha de inicialização, conecte a fonte de alimentação CC incluída e o dispositivo poderá ser ligado durante o carregamento. Se a bateria estiver muito fraca, pode demorar alguns minutos. Se o dispositivo ainda não conseguir ligar, entre em contato com o departamento de atendimento ao cliente e devolva-o para reparo. Se a temperatura for inferior a - 20 °C, não será possível ligar. Por favor, ligue em um ambiente adequado. Depois que o dispositivo for ligado, ele não será afetado pela temperatura e poderá funcionar sem problemas.

2. Interferência da tela sensível ao toque

Em caso de tela sensível ao toque anormal, desconecte a energia ou reinicie ou remova a estática. Se a tela sensível ao toque ainda estiver anormal, entre em contato com o departamento de atendimento ao cliente e devolva-a para reparo.

3. Atualização de uma chave lenta ou com falha

Verifique se a conexão Wi-Fi está normal e se o sinal está bom. Se não puder ser resolvido, verifique se o período de atualização expirou. Em caso afirmativo, entre em contato com o departamento de atendimento ao cliente para resolver.

4. Bater

Se ocorrer alguma falha, pressione e segure o botão liga / desliga por mais de cinco segundos para desligar e reinicie.

5. Falha no teste

Solução: exclua problemas de software ----- atualize novamente o software mais recente ---- incapaz de resolver ---- ofereça feedback ---- Exclua problemas de veículo ---- veículo sem nenhum problema ---- (se permitido) exclua problemas no fio principal ---- substitua o mesmo tipo de fio principal ---- confirme o problema do dispositivo e envie-o de volta para reparo (junto com o fio principal).

6. Incapaz de carregar

Verifique se o carregador tem saída de tensão de 12 V. Em caso de falta de tensão ou tensão anormal, substitua o carregador; se ainda não funcionar após a substituição, entre em contato com o departamento de atendimento ao cliente para reparo (junto com o carregador)

7. Atualização de Software

Solução: Interface DP----Registro do centro pessoal----Conta de login----Insira o aplicativo de atualização----Marque o software a ser atualizado----Marque a atualização em lote (etapas detalhadas: Aplicativo de suporte--Produto instrução--instrução de diagnóstico e atualização).

8. Excluir software

Solução 1: DP----Gerenciamento de dados----Desinstalar modelos de veículos----Marque o modelo de veículo a ser desinstalado---Clique na marca de exclusão no canto superior direito (Detalhes: Consulte desinstalar modelos de veículos na sexta parte da instrução do produto/instrução de diagnóstico).

Solução 2: Entre na interface DP, clique no logotipo do veículo, entre na página da versão do software, pressione e segure até aparecer um prompt e, finalmente, selecione excluir.

9. Troca de idioma do sistema

Entre na interface multifuncional a partir do ícone multifuncional na área de trabalho, selecione "Configurações" --- "Idioma e entrada" --- "Idioma" e selecione o idioma desejado.

